# How to upgrade FW of RS-G1

1. Run "RealScanUI_32.exe", which is just for upgrading FW.


2. Connect RS-G1 to rear USB port of PC.

3. Follow as below image (Click "Init SDK"→ "Init Device" →"Firmware Upgrade")

4. Click "RealScan_G1_v1.03.bin" that is new FW and "Open"

5. It takes approximately 5 seconds for upgrading FW

6. If the FW is upgraded successfully, you can see the success message on the top of the application as below